

Supplementary Kawasaki ZX6R 2003-04



1) Ignition coils

Disconnect Black 12way Sumitomo connector from injectors (see below). From MALE connector (motorcycle main wiring harness) remove MALE pin with Red wire by needle. Remove any rubber seal in connector and place MALE pin with Red wire here.

Place MALE pin with Yellow wire from QS wiring harness where was Red wire.

Remove rubber seal in FEMALE connector on opposite side of Red wire - place FEMALE pin with Red wire from QS wiring harness.

Remove MALE pin with Black wire from Black 12way Sumitomo connector . Insert male pin with Blue and Violet wires from QS wiring harness. Insert Black wire with Male pin into plastic house on the end of Violet wire.

2) Injectors

Disconnect Grey 12way Sumitomo connector from injectors (see below) and remove FEMALE pin with White/Red wire by needle. Put on plastic house on this pin. Insert female pin with White wire from QS wiring harness into free position in Grey 12way Sumitomo connector (instead of White/Red wire). White wire from QS continues to White/Red wire to injectors now.

3) Ground connection

Connect black wire of QS to negative terminal of battery (or to frame of motorcycle)

4) QS sensor

Connect QS sensor to QS wiring harness - black 2 pin connector.

