

supplementary Suzuki GSX1000S



1) Ignition coils

Disconnect connectors from ignition coils and insert connectors of QS. Order is arbitrary. Check if White/Red wire of motorcycle wiring harness is connect with RED wire of QS wiring harness.

2) Secondary (upper) injectors

Disconnect connectors from upper injectors and insert connectors of QS. Order is arbitrary.

3) Gear position sensor connection

Disconnect 3pin white Sumitomo connector from GP sensor and insert connectors from QS.

4) Ground connection

Connect black wire of QS to negative terminal of battery (or to frame of motorcycle)

4) QS sensor

Connect QS sensor to QS wiring harness - black 2 pin connector.

