

Supplementary Yamaha YZF R6 2003-05



1) Injectors connector:

Disconnect 6pin white connector from injectors.

Remove Red/Blue wire from FEMALE connector (unlock pin by needle). Place Yellow wire from QS unit to this position (where was Red/Blue).

Place Red/Blue wire socket to 1pin connector on QS wiring harness to Red wire from QS unit.

Remove Green/Black wire from FEMALE connector (unlock pin by needle). Place Blue+Black wires from QS unit to this position (where was Green/Black).

Place Green/Black wire socket to 1pin connector on QS wiring harness to Black wire from QS unit.

2) Connect black wire (with ring terminal) from QS unit to minus terminal on battery.

3) Connect shifting sensor coupler to QS unit wiring harness - black rectangle coupler.

