

supplementary Kawasaki ZX10R - Plug&Play (2011-15)



1) Ignition coils

Disconnect connectors from ignition coils and insert connectors of QS. Order is arbitrary. Check if RED wire of motorcycle wiring harness is connect with RED wire of QS wiring harness.

2) Gear position switch

Disconnect gear position connector - see picture below - A. Remove female pin with Green/Red wire from plastic body by needle. Insert female pin on (Blue+Violet) wires from QS ecu. Insert Green/Red wire to plastic house on Violet wire.

3) Ground connection

Connect black wire of QS to negative terminal of battery (or to frame of motorcycle)

4) QS sensor

Connect QS sensor to QS wiring harness - black 2 pin connector.

