

supplementary Kawasaki ZX6R to 1999



1) Ignition coils

Disconnect Red wire from ignition coil 1.

Connect Yellow wire from QS unit to ignition coil terminal and Red wire from QS unit to Red wire - see picture below.

Do it same with Red wire on ignition coil 2.

2) RPM connection

Connect Blue wire from QS unit to ignition coil #1-to Black wire. Or to ignition coil #2-to Green. Blue wire from QS have to be connected with Black (or Green) and ignition coil terminal.

3) Ground connection

Connect black wire of QS to negative terminal of battery (or to frame of motorcycle)

4) QS sensor

Connect QS sensor to QS wiring harness - black 2 pin connector.

