



1) Ignition coils

Disconnect Black/White wire from ignition coil 1.

Connect Yellow wire from QS unit to ignition coil terminal and Red wire from QS unit to Black/White wire - see picture below.

Do it same with Black/White wire on ignition coil 2.

2) RPM connection

Connect Blue wire from QS unit to ignition coil #1-to Y/BI wire. Or to ignition coil #2-to BI/Y. Blue wire from QS have to be connected with Y/BI (or BI/Y) and ignition coil terminal.

3) Ground connection

Connect black wire of QS to negative terminal of battery (or to frame of motorcycle)

4) QS sensor

Connect QS sensor to QS wiring harness - black 2 pin connector.

