



1) Ignition coils

Disconnect connectors from ignition coils and insert connectors of QS. Order is arbitrary. Check if ORANGE wire of motorcycle wiring harness is connect with RED wire of QS wiring harness.

2) Injector

Disconnect connectors from injector and insert connectors of QS.

3) Auto-Blipper module

Disconnect connectors from accelerator and insert connectors of AB module. Connect AB module to QS wiring harness.

4) Ground connection

Connect black wire of QS to negative terminal of battery (or to frame of motorcycle)

5) QS sensor

Connect QS sensor to QS wiring harness. Check setting in software - page "Monitor".
Move pedal to higher gear - you have to see green point by Input-Shifter.
Move pedal to lower gear - you have to see green point by Input-Blipper.

