

supplementary

Yamaha YZF R3, MT-03



1) Ignition coils

Disconnect Red/Black wire from ignition coil 1.

Connect Yellow wire from QS unit to ignition coil terminal and Red wire from QS unit to Red/Black wire - see picture below.

Do it same with Red/Black wire on ignition coil 2.

2) RPM connection

Connect Blue wire from QS unit to ignition coil #1-to Orange wire. Or to ignition coil #2-to Grey/Red. Blue wire from QS have to be connected with O (or Gr/R) and ignition coil terminal.

3) Ground connection

Connect black wire of QS to negative terminal of battery (or to frame of motorcycle)

4) QS sensor

Connect QS sensor to QS wiring harness - black 2 pin connector.

